


AIO™ Stand for Vertical Stack

Product Data Sheet



CONTACT INFO

VIP Customer/Technical Support

Email: vip@innova.co

Phone: [\(212\) 204-2700](tel:(212)204-2700)

DISCLAIMER

This documentation is intended for informational use only and should not be construed as a binding representation or contract. This documentation is provided "as is" without warranty of any kind, either express or implied. INNOVA and its affiliates disclaim all liability arising from the use or misuse of this documentation.

Illustrations may not be to scale and all information and dimensions stated herein are subject to change at any time at the sole discretion of INNOVA. Benefits described herein apply only to the extent that the product is installed correctly in the correct application and used for its intended purpose.

INNOVA is constantly innovating and improving its products and reserves the right to modify product design and specifications without notice and without incurring any obligations.

AIO™ STAND FOR VERTICAL STACK

WARNING

Only qualified professionals should install and service this equipment. Improper installation or modifications by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the installation manual and labels attached to the equipment.

AIO® is a registered trademark of INNOVA.

Copyright © 2026 INNOVA. All rights reserved.

1. SPECIFICATIONS

1.1 Specifications

Material	Zinc-coated galvanized steel in sheet metal
Max supported Weight	330 lbs (149.7 kg)
Max Height	12.2 inches (309.9 mm)
Min Height	10.03 inches (254.8 mm)

1.2 What comes in the box

Figure 1. What comes in the box



1.3 Image of full assembly

Figure 2. Full assembly



2. DIMENSIONS

Figure 3. Dimensions




Figure 4. Dimensions




Figure 5. Dimensions



Figure 6. Dimensions




Figure 7. Dimensions





Figure 8. Dimensions



3. INSTALLATION

1. Prepare for installation:

- Remove the screws securing the existing brackets.
- Detach the brackets from the unit.

2. Attach side brackets:

- Install the four side brackets to the underside of the unit base.
- Ensure that they are securely positioned.

3. Install the bottom plate:

- Attach the bottom plate to the four side brackets using the provided screws.
- Ensure that all connections are tight and stable.

4. Insert adjustable feet:

- Insert the four adjustable feet into the bottom plate.
- Verify that each foot is properly threaded and securely fastened.

5. Level the unit:

- Adjust the feet to achieve the desired height.
- Use a level to ensure the unit is correctly aligned and horizontally balanced.

Figure 9. Installation






Figure 10. Installation





With over 20 years of experience in the climate comfort sector, we have a clear goal: growth through innovation. Our team is laser-focused on the conception, development, and production of innovative heating, ventilation, and air conditioning solutions. This mission has developed through bringing together technical skills, creativity, technology, design, Italian passion, and a global vision to achieve the best energy efficiency and performance.

innova.co | **USA:** 216-710-1000 **Canada:** 416-739-1000



© 2026 INNOVA. All rights reserved.

Revised June 23, 2026

AIO™ Stand for Vertical Stack **Product Data Sheet**